

31 01959 10

**INSTRUCTION MANUAL  
FOR**

**TM-2**

**TAPE TRANSPORT**



AMPEX COMPUTER PRODUCTS COMPANY  
P. O. BOX 329, CULVER CITY, CALIFORNIA

Copyright 1962 by Ampex Computer Products Company





AMPEX COMPUTER PRODUCTS COMPANY

## TABLE OF CONTENTS

Section		Page
I	DESCRIPTION/SPECIFICATIONS . . . . .	1-1
1-1	General Description . . . . .	1-1
1-3	Tape Transport . . . . .	1-1
1-12	Head Assembly . . . . .	1-3
1-14	Photosense . . . . .	1-3
1-16	Transport Electronics Assembly . . . . .	1-3
1-18	Manual Control Panel . . . . .	1-4
1-20	Voltage Regulator . . . . .	1-4
1-22	Cooling Fan . . . . .	1-5
1-24	Functional Description . . . . .	1-5
1-33	Specifications . . . . .	1-11
	Operating Characteristics . . . . .	1-11
	Programming . . . . .	1-13
	Outputs . . . . .	1-15
	Controls . . . . .	1-16
	Input Power Requirements . . . . .	1-17
	Environmental . . . . .	1-17
II	INSTALLATION . . . . .	2-1
2-1	Selection of Location . . . . .	2-1
2-7	Uncrating . . . . .	2-2
2-13	Mounting (Custom Installations) . . . . .	2-4
2-15	Cabling . . . . .	2-11
2-17	Head Cable Connections . . . . .	2-13
III	OPERATION . . . . .	3-1
3-1	General . . . . .	3-1
3-3	Operating Controls . . . . .	3-1
3-5	Threading Tape Leader . . . . .	3-1
3-9	Installing File (Supply) Reel . . . . .	3-5
3-11	Manual Operation . . . . .	3-7
3-16	Automatic Operation . . . . .	3-7
3-19	Removing File Reel . . . . .	3-8
3-21	Interlocks . . . . .	3-9
3-24	Preparing Tape Indicators . . . . .	3-9

TABLE OF CONTENTS

Section		Page
IV	CHECKOUT AND ADJUSTMENT . . . . .	4-1
4-1	General . . . . .	4-1
4-4	Preliminary Operations . . . . .	4-1
4-7	Checking Start/Stop Time . . . . .	4-5
4-10	Checking Start/Stop Distance . . . . .	4-8
4-12	Adjusting Capstan Roller Gap and Tape Brake Gap. . . . .	4-9
4-14	Checking Tape Tracking . . . . .	4-12
V	MECHANICAL DESCRIPTION . . . . .	5-1
5-1	General . . . . .	5-1
5-4	Tape Transport . . . . .	5-1
5-27	Transport Electronics Assembly . . . . .	5-8
5-40	Manual Control Panel . . . . .	5-12
5-42	Photosense Unit. . . . .	5-13
VI	ELECTRICAL OPERATION . . . . .	6-1
6-1	Basis of Discussion . . . . .	6-1
6-4	Actuator Control . . . . .	6-1
6-37	Servo System. . . . .	6-12
6-64	Manual Control Panel. . . . .	6-19
6-88	Photosense Unit. . . . .	6-26
VII	MAINTENANCE . . . . .	7-1
7-1	General . . . . .	7-1
7-4	Preventive Maintenance Schedule . . . . .	7-1
7-6	Maintenance Operations. . . . .	7-4
7-7	Checking Servo Amplifier Bias . . . . .	7-4
7-8	Cleaning the Tape Transport . . . . .	7-6
7-9	Checking Capstan Roller Adjustment . . . . .	7-7
7-10	Checking Tape Tracking . . . . .	7-7
7-11	Checking Pack Follower Alignment. . . . .	7-8
7-12	Capstan Roller Adjustment . . . . .	7-8
7-13	Degaussing Tape Path. . . . .	7-11
7-14	Cleaning Rack. . . . .	7-12
7-15	Replacing Air Filters . . . . .	7-13
7-16	Checking and Adjusting Vacuum . . . . .	7-13
7-17	Aligning Chamber Guides . . . . .	7-14
7-18	Checking and Adjusting Reel Servos . . . . .	7-15
7-19	Checking Holddown Operation and Torque . . . . .	7-20



Section		Page
7-20	Checking Actuator Firing Circuitry . . . . .	7-20
7-21	Aligning Pack Follower . . . . .	7-20
7-22	Replacing Thyratrons . . . . .	7-23
7-23	Replacing Anti-Static Strip . . . . .	7-23
7-24	Checking Head Wear . . . . .	7-23
7-25	Adjusting Vacuum Switch . . . . .	7-24
7-26	Replacing Vacuum Tubes . . . . .	7-26
7-27	Replacing Vacuum Blower Brushes . . . . .	7-26
7-28	Checking Capstan Drive Belt . . . . .	7-27
7-28	Checking Capstan Drive Belt . . . . .	7-27
7-29	Replacing Capstan Roller Assemblies, Capstan Assemblies, and Actuators . . . . .	7-27
7-30	Replacing Capstan Drive Belt . . . . .	7-28
7-31	Replacing Chamber Guides . . . . .	7-29
7-32	Replacing Reel Motor Brushes . . . . .	7-29
7-33	Adjusting Holddown Knob Torque . . . . .	7-30
7-34	Replacing Positive Pressure Blower . . . . .	7-30
7-35	Replacing Pack Follower Assemblies . . . . .	7-31
7-36	Replacing Reel Motors . . . . .	7-31
7-37	Replacing Capstan Drive Motor . . . . .	7-32
7-38	Adjusting Reel Motor Brakes . . . . .	7-33
7-39	Troubleshooting Chart. . . . .	7-34
7-40	Maintenance Tools . . . . .	7-39
VIII	SCHEMATIC DIAGRAMS . . . . .	8-1
IX	ILLUSTRATED PARTS BREAKDOWN . . . . .	9-1





LIST OF ILLUSTRATIONS

Figure	Title	Page
SECTION I -- DESCRIPTION/SPECIFICATIONS		
1-1	Tape Transport . . . . .	1-1
1-2	Head Assembly . . . . .	1-3
1-3	Transport Electronics Assembly . . . . .	1-3
1-4	Manual Control Panel . . . . .	1-4
1-5	Voltage Regulator . . . . .	1-5
1-6	Instantaneous Speed Variation . . . . .	1-12
1-7	Stop Delay Requirements . . . . .	1-14
SECTION II -- INSTALLATION		
2-1	Dimensions and Clearances, Ampex Cabinet Rack . . . . .	2-3
2-2	Tape Transport Mounting . . . . .	2-5
2-3	Transport Electronics Assembly Mounting . . . . .	2-7
2-4	Manual Control Panel Mounting . . . . .	2-8
2-5	Voltage Regulator Mounting . . . . .	2-9
2-6	Cabling Diagram . . . . .	2-10
2-7	Typical Control Circuitry . . . . .	2-12
2-8	Head Cable Connections . . . . .	2-14
SECTION III -- OPERATION		
3-1	Operating Controls, Manual Control Panel . . . . .	3-2
3-2	Tape Threading Path . . . . .	3-3
3-3	Mounting a File Reel . . . . .	3-4
3-4	Connecting Leaders . . . . .	3-6
3-5	Placement of Photosense Tabs on Tape . . . . .	3-10
SECTION IV -- CHECKOUT AND ADJUSTMENT		
4-1	Servo Amplifier Adjustment Points . . . . .	4-3
4-2	Adjusting Servo Transducer . . . . .	4-3
4-3	Adjusting Servo Gain . . . . .	4-5
4-4	Test Set-up, Start/Stop Time Measurement . . . . .	4-6
4-5	Typical Waveforms, Start/Stop Time . . . . .	4-7
4-6	Test Set-up, Start/Stop Distance Measurement . . . . .	4-9
4-7	Capstan Roller Adjustment Points . . . . .	4-10
4-8	Tape Guide Adjustment Points . . . . .	4-13 and 4-14

LIST OF ILLUSTRATIONS

Figure	Title	Page
SECTION V -- MECHANICAL DESCRIPTION		
5-1	Interconnection of Units . . . . .	5-2
5-2	Tape Transport: Front View . . . . .	5-3
5-3	Tape Transport: Rear View . . . . .	5-4
5-4	Head Assembly . . . . .	5-7
5-5	Transport Electronics Assembly. . . . .	5-9
5-6	Manual Control Panel . . . . .	5-12
SECTION VI -- ELECTRICAL OPERATION		
6-1	Block Diagram, Actuator Control AC-400 . . . . .	6-2
6-2	Waveshape, Anode of V404 . . . . .	6-3
6-3	Waveshapes, C107/Anode V404 . . . . .	6-4
6-4	Waveshape, Discharge Current C107 . . . . .	6-4
6-5	Waveshapes, Cathode/Grid V104 . . . . .	6-5
6-6	Waveshapes, Typical AC-400 Input/Resulting Pulse . . . . .	6-7
6-7	Partial Schematic, AC-400 (Forward Control) . . . . .	6-9
6-8	Partial Schematic, AC-400 (Forward Interlock) . . . . .	6-10
6-9	Block Diagram, Reel Servo System . . . . .	6-13
6-10	Block Diagram, Servo Oscillator OSC-700 . . . . .	6-15
6-11	Waveshape, Typical Oscillator Output. . . . .	6-15
6-12	Partial Schematic, SA-500 (Demodulator) . . . . .	6-17
6-13	Partial Schematic, SA-500 (First Stage) . . . . .	6-18
6-14	Partial Schematic, SA-500 (Second Stage) . . . . .	6-19
6-15	Partial Schematic, SA-500 (Final Stage) . . . . .	6-20
6-16	Waveshapes, Relationship Grid/Anode Voltages . . . . .	6-21
6-17	Block Diagram, Photosense Electronics . . . . .	6-27
SECTION VII -- MAINTENANCE		
7-1	Cleaning Head Assembly. . . . .	7-6
7-2	Cleaning Sensing Slots. . . . .	7-7
7-3	Capstan Roller Adjustment Points . . . . .	7-9
7-4	Head Demagnetization. . . . .	7-12
7-5	Vacuum Level Adjustment Point . . . . .	7-14
7-6	Vacuum Test Assembly . . . . .	7-14
7-7	Tape Guide Adjustment Points. . . . .	7-15
7-8	Servo Amplifier Adjustment Points . . . . .	7-16



Figure	Title	Page
7-9	Adjusting Servo Transducer . . . . .	7-17
7-10	Adjusting Servo Gain . . . . .	7-19
7-11	Measuring Tape Packer Arm Tension . . . . .	7-21
7-12	Cutaway View, Tape Packer Assembly . . . . .	7-21
7-13	Location of Pack Follower Switch . . . . .	7-22
7-14	Checking Head Wear . . . . .	7-24
7-15	Adjusting Loop Warning Switch . . . . .	7-25
7-16	Capstan Drive Belt Path . . . . .	7-28
7-17	Measuring Capstan Drive Belt Tension . . . . .	7-29
7-18	Adjusting Capstan Drive Belt Tension . . . . .	7-29
7-19	Reel Brake Adjustment Points . . . . .	7-33

SECTION VIII -- SCHEMATIC DIAGRAMS

8-1	Schematic Diagram, Tape Transport . . . . .	8-1
8-2	Schematic Diagram, Composite Control System . . . . .	8-3
8-3	Schematic Diagram, Composite Actuator Control . . . . .	8-5
8-4	Schematic Diagram, Actuator Control Unit AC-400 . . . . .	8-7
8-5	Schematic Diagram, Composite Servo System . . . . .	8-9
8-6	Schematic Diagram, Servo Oscillator OSC-700 . . . . .	8-11
8-7	Schematic Diagram, Servo Amplifier SA-500 . . . . .	8-13
8-8	Schematic Diagram, Electronics Power Supply PS-100 . . . . .	8-15
8-9	Schematic Diagram, Servo Motor Power Supply PS-200 . . . . .	8-17
8-10	Schematic Diagram, Connector Chassis CC-300 . . . . .	8-19
8-11	Schematic Diagram, Manual Control Panel CU-800 . . . . .	8-21
8-12	Schematic Diagram, Photosense Base Card . . . . .	8-23
8-13	Schematic Diagram, Photosense Base Card . . . . .	8-25
8-14	Schematic Diagram, Photosense Base Card . . . . .	8-27
8-15	Schematic Diagram, Photosense Power Supply . . . . .	8-29
8-16	Schematic Diagram, Photosense Chassis Wiring . . . . .	8-31
8-17	Schematic Diagram, Photosense Chassis Wiring . . . . .	8-33
8-18	Schematic Diagram, Photosense Chassis Wiring . . . . .	8-35

SECTION IX -- ILLUSTRATED PARTS BREAKDOWN

9-1	TM-2 Tape Transport . . . . .	9-3
9-2	TM-2 Tape Transport Final Assembly . . . . .	9-8
9-3	Read/Write Head Assemblies . . . . .	9-12
9-4	Head Cable and Box . . . . .	9-14

LIST OF ILLUSTRATIONS

Figure	Title	Page
9-5	Photosense System . . . . .	9-18
9-6	Positive Pressure Filter Assembly . . . . .	9-30
9-7	Vacuum Blower and Elapsed Time Meter. . . . .	9-32
9-8	Supply Reel, Take-Up Reel, and Reel Motors . . . . .	9-36
9-9	Capstan Drive Motor Assembly . . . . .	9-40
9-10	Positive Pressure Blower . . . . .	9-44
9-11	Upper Servo Control . . . . .	9-48
9-12	Lower Servo Control . . . . .	9-52
9-13	Oscillator and Housing . . . . .	9-56
9-14	Reel Brakes. . . . .	9-60
9-15	Vacuum Chambers . . . . .	9-64
9-16	Precision Plate . . . . .	9-68
9-17	Cable, Switches, Vacuum Tubing, and Main Frame. . . . .	9-76
9-18	Transport Access Door . . . . .	9-82
9-19	Transport Electronics Assembly. . . . .	9-86
9-20	Electronics Power Supply PS-100 . . . . .	9-90
9-21	Servo Motor Power Supply PS-200 . . . . .	9-98
9-22	Connector Chassis CC-300 . . . . .	9-102
9-23	Actuator Control Unit AC-400 . . . . .	9-106
9-24	Servo Amplifier SA-500 . . . . .	9-110
9-25	Manual Control Panel . . . . .	9-114
9-26	Cabinet and Dolly Assemblies . . . . .	9-120