



Figure 8-11  
Schematic Diagram,  
Manual Control Panel CU-800