

400

408

KS I	Zeile J-Schreib	Zeile J-Lesen	Spalte J-Schreib	Spalte J-Lesen	T°C Raum	T°C KS-Fühler
alte Einstellg.	376	376	376	376	23	<u>12,6</u>
neue Einstellg.	376	=	=	=	23	<u>12,7</u> 31,5
KS II	2G mit 2G von KS IV vertauscht					
alte Einstellg.	385	380A	385	440		<u>13</u> 25
neue Einstellg.	375A	370A	387	387	23	<u>13,1V</u> 24,5
KS III						
alte Einstellg.	376	=	=	=	=	<u>12,65</u> 32,1
neue Einstellg.	375				23	<u>12,6</u> 32,5°
KS IV						
alte Einstellg.	385	=	=	=		<u>13</u> 25
neue Einstellg.	385	=	=	=	23	<u>12,95</u> 25,5°
KS V						
alte Einstellg.	37,6	=	=	=		<u>12,6</u> 32,5
neue Einstellg.	37,4	=	=	=	23	<u>12,6</u> 33
KS VI						
alte Einstellg.	376	=	=	=		<u>13,1</u> 24,0
neue Einstellg.	38,5	=	=	=	23	<u>13</u> 25

alle Teileinheiten u. KS-Matrix
von KS IV und KS VI ver-
tauscht (11.7.66) Dr